

# BEOMAT

## PARTS LIST

### &

## EXPLODED VIEWS

Furnished by:



### **QUALITY REPLACEMENT PARTS**

Quality Replacement Parts, Inc.  
9099 Bank St, Ste B  
Valley View, OH 44125  
1-800-742-0425

VIEW, PART#. DIM.

NAME OF PART.

VIEW, PART#. DIM.

NAME OF PART.

1	2000-0	M 12 X 3	ALLEN BOLT	67	2066-4	5.3 X 10 X 1	WASHER
2	2001-7	M 12	ROD END 12 HS A	68	2067-2	M5 X 18	SCREW
3	2002-4	13 X 24 X 4	WASHER	69	2068-2	M5 X 9	SCREW
4	2003-6	15 X 1	LOCK CLIP	70	2069-1	M8 X 30	BOLT HEX HEAD
5	2004-13	1/2" X 3/16"	CHAIN LOCK	71	2070-4	8.4 X 16 X 1.5	WASHER
6	2005-13	1/2" X 3/16" S	CHAIN	72	2071-3	M8	NUT
7	2006-0	M6 X 16	BOLT	73	2072-9		BASE PLATE SKEET
8	2007-4	6.4 X 12 X 1.5	WASHER	74	2073-8-9		TURN BUCKLE
9	2008-14	1/2" X 3/16"	CHAIN SPROCK.	75	2074-8		PART OF MAIN CHASSY
10	2009-1	M10 X 50	BOLT	76	2075-4	13 X 24 X 1.7	WASHER
11	2010-7	GE 12 C	BEARING	77	2076-3	M12 X 6	NUT
12	2011-3	M8	NUT	78	2077-8		BRACKET/TURN BUCKLE
13	2012-8		VERTICAL CON. ROD	79	2078-8		TURNTABLE
14	2013-10		TERMINAL STRIP	80	2079-8		CON. ROD, HOR. DRV.
15	2014-8		COVER FOR DRIVE	81	2080-8		SPRING SUPP. UPPER
16	2015-8		RUBBER SKIRT	82	2081-8		SPRING
17	2016-10	18.6	NUT MACROLON	83	2082-8		SPRING SUPP LOWER
18	2017-10	18.6-15.2	CABLE BUSHING	84	2083-3	M12	NUT - NYLOCK
19	2018-10	20MM	CABLE BUSHING	85	2084-0	M12 X 35	ALLEN BOLT
20	2019-8		INTERRUPTOR BOX	86	2085-0	M6 X 30	ALLEN BOLT
21	2020-10	15MM	CABLE BUSHING	87	2086-0	M6 X 20	ALLEN BOLT
22	2021-10	22MM	CABLE BUSHING	88	2087-15	RATIO 90:1	REDUCT. GEAR
23	2022-8		CHASSIS/TRAP DRIVE	89	2088-5	VACANT #	
24	2023-10	BK 4	TERMINAL	90	2089-3	M12 X 10	NUT
25	2024-5	M6 X 10	SET SCREW	91	2090-8		PULLEY/VERT.MOVE
26	2025-7	UCF205 J	BEARING ASSY	92	2091-8-9		GREASE FITTING
27	2026-10	18,6MM	CABLE BUSHING	93	2092-2	M4 X 30	SCREW
28	2027-10		ELECTR. CONN. SK.	94	2093-10		COVER
29	2028-10		ELECTR. CONN. TR	95	2094-10		RUBBER SEAL
30	2029-8		CARRIER CHASSIS	96	2095-10	.12KW	EL. MOTOR 1800rpm
31	2030-15	RATIO 64-1	REDUCTION GEAR	97	2096-8		SPAC./VERTICAL DRIVE
32	2031-15		CLUTCH HOUSING	98	2097-19	5 X 30	KEY
33	2032-5	M5 X 5	SET SCREW	99	2098-4	13 X 24 X 2	WASHER
34	2033-5	M5 X 12	SET SCREW	100	2099-10		ELECT. JNCT BOX
35	2034-10		CLUTCH	101	2100-0	VACANT #	
36	2035-10		ROTOR	102	2101-0	M12 X 30	ALLEN BOLT
37	2036-0	M6 X 20	ALLEN BELT	103	2102-7	M30208	BEARING
38	2037-10		STATOR	104	2103-7	30208	BEARING RACE
39	2038-17		SPACER(spec. thick.)	105	2104-8		HOUSING/TURNTABLE
40	2039-18	80 X 5	O-RING	106	2105-8	VACANT #	
41	2040-11	4 X 16	TENSION PIN	107	2106-21	50 X 80 X 10	SEAL
42	2041-2	M4 X 15	SCREW	108	2107-8		SPACER
43	2042-10		COVER	109	2108-8		SPACER
44	2043-10		RUBBER SEAL	110	2109-3	KM8	SPANNER NUT
45	2044-10	0.25kw	EL.MOTOR 1200rpm	111	2110-8-9		BELT COVER
46	2045-19	8 X 31	KEY	112	2111-8-9		CHASSIS
47	2046-14	1/2" X 3/16	SPRKT SPEC. # TEETH	113	2112-4	C13	CONE WASHER
48	2047-5	8 X 16	SET SCREW	114	2113-8		SUPPORT BRCT (TRAP)
49	2048-10		EL JUNCTION BOX	115	2114-	VACANT#	
50	2049-8-9	15MM	SPAC. SPRING TENS.	116	2115-	VACANT#	
51	2050-8-9	10MM	SPAC. SPRING TENS.	117	2116-0	M10 X 20	ALLEN BOLT
52	2051-8		CHAIN TENS. BRKT	118	2117-4	10 X 18 X 2	WASHER
53	2052-1	M8 X 30	BOLT	119	2118-0		
54	2053-10		ADAPTER (MACROLON)	120	2119-8-9		REDUCT. GEAR BRKT
55	2054-7		BEARING ASSY	121	2120	VACANT#	
56	2055-1	10 X 25	BOLT HEXHEAD	122	2121-	VACANT#	
57	2056-8-9	5MM	SPAC. SPRING TENS.	123	2122-1	M10 X 50	BOLT
58	2057-8-9	2MM	SPAC. SPRING TENS.	124	2123-21		VENT PLUG/ LATE/PR.
59	2058-5	10 X 22 X 2	WASHER	125	2124-1	M8 X 20	CARIAGE BOLT
60	2059-4	13 X 17 X 0.6	WASHER	126	2125-1	M5 X 16	SELF TRAPPING BOLT
61	2060-3	M10	NUT	127	2126-8-9		PIVOT BRACKET
62	2061-10	18.6	RUBBER BUSHING	128	2127-15	RATIO 45:1	REDUCT. GEAR
63	2062-10	18-6	CHROMED BRASS NUT	129	2128-9	SKEET A-54	DRIVE BELT (G-7560)
64	2063-10		EL JUNCTION BOX	130	2129-8	TRAP A-56	DRIVE BELT (G-7570)
65	2064-10		RUBBER SEAL	131	2130-9	D/D-95	BELT PULLEY SKEET
66	2065-10		COVER	132	2131-8	D/D-118	BELT PULLEY TRAP

## VIEW, PART#. NAME OF PART.

## VIEW, PART#. DIM.


## NAME OF PART.

133	2132-10		SCREW (PLASTIC)	197	2196-8-9		BRAKE BAND
134	2133-10	0.25 KW	EL. MOTOR 1800RPM	198	2197-8-9		BEARING PLATE
135	2134-10		COVER	199	2198-7	AS-25	SPRAGUE
136	2135-10		UBBER SEAL	200	2199-0	M8 X 30	BOLT ALLEN
137	2136-10		TRAFO (BOX ONLY)	201	2200-1	10 X 25	BOLT HEX HEAD
138	2137-1	VACANT		202	2201-8-9		EXCENTER
139	2138-10	24 VDC	COUNTER	203	2202-11	6 X 40	TENSION PIN
140	2139-10	VACANT		204	2203-19	8 X 63	KEY
141	2140-2	M4 X 25	SCREW	205	2204-8-9		MAIN SHAFT
142	2141-4	4.3 X 8 X 1	WASHER	206	2205-8-9		SPRING CONNNECTOR
143	2142-3	M4	NUT	207	2206-8-9		STUD
144	2143-3	VACANT		208	2207-4		SPRING WASHER
145	2144-4	VACANT		209	2208-4		BRASS WASHER
146	2145-8-9		STUD (FOR GUIDE RAIL)	210	2209-4		SPRING WASHER
147	2146-8-9		TREAD BUSHING	211	2210-5	M8 X 25	SET SCREW (PIN TYPE)
148	2147-8-9		GUIDE RAIL	212	2211-8-9	820MM	900 MAG. PROFILE
149	2148-8-9		LAUNCHING TABLE	213	2212-8-9		MAGAZINE LOCK
150	2149-1	VACANT		214	2213-3	M16	NUT
151	2150-8-9		BRACKET	215	2214-7	6002 2 RS	BEARING
152	2151-8-9	M8	LINK	216	2215-8-9	M16	THREADED ROD
153	2152-4	9 X 28 X 2	WASHER	217	2216-8-9		SPRING TENSION ROD
154	2153-1	M8 X 20	BOLT HEX HEAD	218	2217-4	20 X 52 X 8	WASHER
155	2154-8-9		BRUSH ONLY	219	2218-8-9	LT-16	EYELET
156	2155-8		BRACKET	220	2219-8-9	(A) (B) (C)	M/ SPRING SP./COLOR
157	2156-0	M6 X 35	ALLEN BOLT	221	2220-20		BUSHING
158	2157-10		ELECTRO MAGNET	222	2221-20		BUSHING
159	2158-8-9		ELEVATOR	223	2222-6	A30	LOCK CLIP
160	2159-2	M3 X 30	SCREW	224	2223-8-9		DRIVE WHEEL
161	2160-4	3.2 X 6 X 0.5	WASHER	225	2224-8-9		MAGAZINE SHAFT
162	2161-8		BRACKET	226	2225-0	M8 X 35	ALLEN BOLT
163	2162-10		MICRO SWITCH	227	2226-0	M6 X 10	BOLT (COUNTER SUNK)
164	2163-4	3.2 X 6 X 0.4	LOCK WASHER	228	2227-8-9		BRUSH W/BRACKET
165	2164-3	M3	NUT	229	2228-8-9		GUIDE FINGER
166	2165-0		SWITCH HOUSING	230	2229-8-9		MAGAZINE PLATE
167	2166-0	M8 X 20	ALLEN BOLT	231	2230-8-9		LEAF SPRING BRACKET
168	2167-2	M6 X 25 (30)	BOLT FOR L-ARM	232	2231-8-9		LEAF SPRING
169	2168-0	M10 X 30	ALLEN BOLT	233	2232-8-9		MAGAZINE STRUCTURE
170	2169-8-9		SPRING	234	2233-8-9	365MM	400 MAG. PROFILE
171	2170-13		SHOWN F/REF. ONLY	235	2234-8-9	600MM	700 MAG. PROFILE
172	2171-13	21/4-13	LOCK CLIP	236	2235-18		O-RING
173	2172-20		BUSHING	237	2236-6	A-15	LOCK CLIP
174	2173-13		RECEIVER	238	2237-4	15 X 26 X 2	WASHER
175	2174-13		CHAIN LOCK	239	2238-17		TARGET RET./WHEEL
176	2175-17		LOAD EQUALIZER	240	2239-8-9		SPACER
177	2176-8-9		BRACKET (THREADED)	241	2240-8-9		PIVOT ARM
178	2177-8-9		BRACKET	242	2241-9		SUPP. BRKT (SKEET)
179	2178-7	6000 2 RS	BEARING	243	2242-8-9	6 X 80	TENSION PIN
180	2179-1	M10 X 30	BOLT HEXHEAD	244	2243-8		MAIN EL. BOX (TRAP)
181	2180-1	M6 X 30	BOLT HEXHEAD	245	2244-9		MAIN EL. BOX (SKT)
182	2181-8-9		PARALLEL ARM BRKT	246	2245-8		CONTROL BOX MJT
183	2182-8-9		P-ARM (LOWER)	247	2246-8		CONTROL BOX MT
184	2183-8-9		P-ARM (UPPER)	248	2247-10	IPM 45060	ST. RELAY 1800rpm
185	2184-0	M6 X 16	BOLT (P-ARM ASSY)	249	2248-10	80 MF	CAPAC. 1200rpm M
186	2185-8-9		LAUNCHING ARM	250	2249-10	120 MF	CAPAC. 1800rpm M
187	2186-0	M6 X 22	BOLT (COUTERSUNK)	251	2250-10	24V	RELAY
188	2187-8-9		DRIVEMEMBER	252	2251-10	12V	RELAY
189	2180-0	M8 X 25 (12.9)	ALLEN BOLT 8-GRADE	253	2252-8-9	400	MAGAZINE COMPL.
190	2189-0	M8 X 25	ALLEN BOLT	254	2253-8-9	700	MAGAZINE COMPL.
191	2190-8-9		FLANGE	255	2254-8-9		DRIVE COMPL.
192	2191-8-9		BELT PULLEY	256	2255-8		HORIZ. DRIVE COMPL.
193	2192-7	6006 2RS	BEARING	257	2256-10		RELEASE BOX (SKEET)
194	2193-8-9		L-ARM CARRIER	258	2257-10		RELEASE BOX (TRAP)
195	2194-8-9		CAM	259	2258-10		FAN COVER LARGE
196	2195-0	M6 X 45	ALLEN BOLT	260	2259-10		FAN COVER SMALL
				261	2260-10		FAN (LARGE)

VIEW, PART#. DIM. NAME OF PART.

VIEW, PART#. DIM. NAME OF PART.



262	2261-10		FAN (SMALL)	289	2288-10		TIMER INT. SKEET 12V
263	2262-21		PINION SEAL	290	2289-10	5 X 20MM	FUSE 500Ma (0.5 AMP)
264	2263-21		SHAFT SEAL	291	2290-8-9	900 TARGET	MAGAZINE COMPLETE
265	2264-21		TOP COVER SEAL	292	2291-8-9		SAFEGUARD
266	2265-21		SHAFT SEAL	293	2292-2		SCREW F/COV. PLATE
267	2266-10		CAPASITOR	294	2293-8-9		COV. PLATE F/CLUTCH
268	2267-10		RELAY SOCKET	295	2294-8		VERT. DRIVE COMPL
269	2268-10	110V-24V DC	TRANSFORMER	296	2295-2		SCREW/ BUTTON BOX
270	2269-10		SWITCH	297	2296-10		24V TIMER
271	2270-10		IND.R LIGHT ASSY	298	2297-10	110V	SKEET TIMER
272	2271-10		IND. LIGHT BULB	299	2298-10		110V AC RELAY
273	2272-10		INTERRUPTOR	300	2299-10		110V AC COUNTER
274	2273-10	10 AMP	OVER LOAD BREAKER	301	2300-7		COMPL P-ARM ASSY
275	2274-10	3 AMP	OVER LOAD BREAKER	302	2301-10		RADIO RELEASE
276	2275-10		SWITCH SNAP ACT.	303	2302-10		EXTRA TRANSMITTER
277	2276-10		RUBBER CAP	304	2303-10		CTRL BOX/ (SHELL)
278	2277-10	SKT/TRP	TOP COV.,SPEC.T/S	305	2304-10		MAIN EL/BOX (SHELL)
279	2278-10		BOX (BOTTOM ONLY)	306	2305-10		110V REL. CORD SKT
280	2279-10	18/2-SJ(100')	TRAP (CORD ONLY)	307	2306-10		INTERRUPTER PEG
281	2280-10	18/3-SJ(100')	SKEET (CORD ONLY)	308	2307-6		C - CLIP
282	2281-10	18/2-SJ(100')	TRP RELEASE CMPL	309	2308-10		HUB
283	2282-10	18/3-SJ(100')	SKT RELEASE CMPL	310	2309-6		C - CLIP
284	2283-10	TRAP	TOP COV. (W/SWI.)	311	2310-10		ROCKER
285	2284-10	SKEET	TOP COV.(W/SWI.)	312	2311-10		SWITCH 483(MICRO)
286	2285-10		MIDGET TWIST LOCK(F)	313	2312-10	2 MIN	INTER. 3354 MOTOR
287	2286-10		MIDGET TWIST LOCK(M)	314	2313-10	10' - 1.5 X 5	CORD 5 CONDUCTOR
288	2287-10	IPM-449	ST. RELAY 1200rpm M	315	2314-10	10' - 1.5 X 3	CORD 3 CONDUCTOR




②③ 400 TARGET MAGAZINE (COMPLETE)

②④ 700 TARGET MAGAZINE (COMPLETE)

②⑤ 900 TARGET MAGAZINE (COMPLETE)







# EXPLODED VIEW OF MAGAZINE, LAUNCHER SUBASSEMBLY

SCALE: NONE  
 DATE: 8-15-86  
 ALL DIMENSIONS  
 IN INCHES  
 UNLESS OTHERWISE SPECIFIED

REVISED: 8-4-88  
 By: Clay Target Enterprises  
 1







LATE PRODUCTION  
COVER PLATE FOR  
CLUTCH ACCESS

COMPLETE LAUNCHER DRIVE UNIT

BEOMAT MS, MJT & MT

Model: NONE  
Date: 30 AUG 84  
EXPLODED VIEW OF LAUNCHER DRIVE  
ASSEMBLY


REVISED: 6-4-88

By: Clay Target Enterprises


DATE: 7-5-87

2







MT400 HORIZONTAL/VERTICAL DRIVE P



ATE

BEOMAT MT, MJT & MS		
ORIGIN: NONE	DATE: 14 SEP 86	BY: J. J. Wilson
EXPLODED VIEW OF VERTICAL DRIVE SUBASSEMBLY AND BASE PLATES		DATE: 7-5-87
REVISED: 8-1-88	By: Clay Target Enterprises	
		3







<b>BEOMAT MT, MJT 400</b>		
MODEL: NONE	REVISED BY: <i>[Signature]</i>	REVISION: 7-5-87
DATE: 9-28-86	EXPLODED VIEW OF HORIZONTAL DRIVE SUBASSEMBLY	
REVISED: 8-4-88	By: Clay Target Enterprises	4



110VAC, 12 or 24 V.D.C. SKEET LAUNCHER RELEASE CORD CIRCUIT




24 V.D.C. TRAP LAUNCHER RELEASE CORD CIRCUIT





BEOMAT MODELS 700 MS, MT AND MODELS 400 MT, MS, MJT			
REVISION	NONE	DATE	16NOV86
BY	John A. Schmitt	CHECKED	17-11-87
PICTORIAL VIEW, WIRE HARNESS ROUTING, ELECTRICAL BOXES			
REVISED: 8-4-83	By: Clay Target Enterprises		5A




# SINGLE SKEET LAUNCHER WITH EXISTING 110 VAC SYSTEM




## 110 VAC ON-OFF-RELEASE SKEET




## 110 VAC TIMER (SKEET)





# 24 V.D.C. SINGLE SKEET LAUNCHER INTERIALLY POWERED RELEASE CIRCUIT (PRE-WIRED FOR RADIO CONTROL)




# 24 V.D.C. TRAP LAUNCHER PRE-WIRED FOR RADIO CONTROL





BROMAT MODELS 700 MS, MT AND MODELS 400 MT, MS, MJT			
WIRE	NONE	DATE	16 NOV '84
BY	By: Clay Target Enterprises	DATE	11-20-84
PICTORIAL VIEW, WIRE HARNESS ROUTING, ELECTRICAL BOXES			
REVISED: 8-4-88			











# Midget twist lock connector




## Typical switch




## RELEASE CORDS







LAUNCHER & HORIZONTAL DRIVE MOTORS



VERTICAL DRIVE MOTOR



DESIGN: None	DATE: 7-5-82	BY: Clay Target Enterprises
ELECTRICAL BOXES		
7		

REVISED: 8-4-88



**INSTALLATION AND OPERATING  
GUIDE**

**FOR BEOMAT MT400, MJT400, 700.**

# **WARNING**

ANY CLAY TARGET LAUNCHER REGARDLESS OF MANUFACTURE, BY THE NATURE OF ITS PURPOSE, CREATES A CERTAIN HAZARD WHERE THE OWNER/USER MUST PROVIDE FOR THE SAFE OPERATION OF SUCH UNIT AT HIS/HER/THEIR OWN EXPENSE AND RESPONSIBILITY.

DO NOT INSTALL THE LAUNCHER SO; THAT THE LAUNCHING ARM AREA IN THE FRONT, OR THE TARGET EXIT AREA AT THE RIGHT FRONT CORNER OF THE MACHINE IS UNPROTECTED. FURTHER, DO NOT ALLOW ENTRANCE TO THE HOUSE ON THE LEFT SIDE OF THE MACHINE, (THE MACHINE'S OWN LEFT SIDE).

IT IS REQUIRED THAT THE ELECTRICAL CONTROL BOX IS MOUNTED IN SUCH A LOCATION, USUALLY AT THE UPPER RIGHT FRONT CORNER OF THE TRAP HOUSE THAT THE LAUNCHER MAY BE RELEASED BY IT'S WIRE REMOTE SWITCH BEFORE ANYONE ENTERS THE HOUSE.


KEEP THE MACHINE AREA CLEAN AT ALL TIMES, REMOVE ALL EMPTY TARGET BOXES - IT GREATLY REDUCES SAFETY HAZARDS.

SHUT OFF POWER AND RELEASE THE LAUNCHER BEFORE PERFORMING ANY WORK WHATSOEVER IN THE HOUSE - WHEN LOADING TARGETS, OR MAKING ANY CHANGES ON THE LAUNCHER ITSELF.

WARNING PAGE

## MJT 400 AND MT 400 Installation / Trap House

To ease the installation, remove the 4 bolts in the magazine center, (do not remove the circlip) and lift the magazine straight off the launcher, re-assemble in reverse order. Before installing the Beomat launcher, please remove the existing Winchester plank, it will not be needed with this machine. Based on the existing trap house, built as per the old Winchester specifications, the MT, or MJT400 will install onto the pier as per the dotted line. Please note that the base of the machine will be offset about 3 - 5° to the right. While the weight distribution of the machine is such that the launcher may be bolted onto the pier as is, additional support under the right side of the base is recommended. The red line on the machine base should correspond with the centerline of the house. It is recommended that the entrance to the trap house be on machines own right side, since the launching arm swings out on the machines own left side. It is also recommended that the control box, as seen on the opposite page, be fastened onto the trap house wall in the upper right side corner of the house as indicated by the dotted line. This provides easy and safe access to the safe release toggle switch, before entering the trap house. Stay clear of the house opening when releasing the machine.




## Machine Installation

Shown here is the picture of the machine base with its red line across, this line should reasonably well correspond with the centerline of the house. The diagonal line in front of the turntable is your guide to set the machine to throw a target straight ahead. When the leading edge of the turn table is parallel with this line, the machine will throw a target approximately center field. The connecting rod shown will change the angle of spread, or width of the field. There are six hole positions on the turntable, the first hole at the tip of the table would be No. 1. The angle of Spread as follows;

- |                   |                   |
|-------------------|-------------------|
| #1, = approx. 32° | #2 = approx. 38°  |
| #3, = approx. 45° | #4 = approx. 60°  |
| #5, = approx. 75° | #6 = approx. 90°. |

The rod may also be used as a windage adjustment in that the rod is threaded, and thus the rod end may be adjusted to compensate for cross winds on the field.




## Installation setup / target trajectory adjustments.

With the machine temporarily fastened on the pier, the **launching arm guard** and the launching arm installed. You having read all pages in this small booklet, and familiarized yourself with the operation of this new launcher. Please load a small number of targets in each magazine position and proceed as follows. To find the exact dispersion of targets on the field, stop the horizontal oscillation by turning off the switch in the machines left most position. Test fire a couple of targets and note the target path in reference to the left field marker, repeat the same procedures to the right side of the field, adjust by turning the entire launcher on the pier as needed. Repeat this procedures until the targets are thrown an equal distance from the field markers. Then secure the launcher to the pier. PLEASE CONDUCT ALL OPERATIONS SAFELY.

The adjustment for a level target flight is located on the inside of the bracket shown, loosen the two fasteners and adjust the vertical bolt until level flight is obtained, tighten the fasteners.

The length of the vertical connecting rod may be adjusted to change the entire "vertical window" up or down as required at your location.

A fine-tuning of the target height in stationary mode can be done by turning the knurled knob at the end of the vertical motor. --- For the MJT400, a turnbuckle will provide the vertical setting.




## Electrical Controls/connections.

The Beomat MT or MJT400 are equipped with a wire remote control box allowing for safe operation from the outside of the trap house.


The toggle switch at the end of box must be on for normal operation together with the launcher switch on the box. It then serves as a safe release switch in its momentary on position before the launcher switch is turned off.

The center switch operates the horizontal oscillations, and the right side switch (for MT-models) provides the vertical oscillation.

A midget twist lock receptacle at the end of the box is for the pull cord.



## Installation setup / spring tension adjustment.



A spacer system is utilized for the changing of the spring tension, (changing of target throwing distance). Two different systems for setting the target flight distance may be used. ONE, the main spring is installed without pre-load, and the spacers may be used to obtain the desired distance with the spring as is. TWO, that the lock nut at the end of the spring be loosened and by turning the eyelet on the outside of the machine clockwise, thus pre-loading the spring. When the desired throwing distance is obtained, tighten the lock nut and use the spacer system for quick changes of more demanding games. The thick spacer will increase the target flight distance by about 10 yards and the other spacers in descending order down to 1 yard.



# ADJUSTMENT GUIDE

**YOUR BEOMAT LAUNCHER HAS UNDERGONE COMPLETE PRE-DELIVERY SERVICE, AND SHOULD NOT REQUIRE ANY OTHER ADJUSTMENTS THAN THE SETUP PROCEDURES AS DESCRIBED ON THE PREVIOUS PAGES. IF THE LAUNCHER IS NOT PERFORMING PROPERLY AFTER INSTALLATION, (THE MACHINE MAY HAVE BEEN EXPOSED TO FREIGHT DAMAGE). IF SO, PLEASE CALL BEOMAT OF AMERICA IMMEDIATELY, AT ANY TIME, (408) 379-4829. IF AFTER BUSINESS HOURS PLEASE REMAIN ON THE LINE, THE CALL WILL TRANSFER TO A SELECTED TECHNICAL SUPPORT PHONE AFTER SEVEN RING SIGNALS.**

## **IF YOUR LAUNCHER IS NOT PERFORMING CORRECTLY, BEFORE ANY ADJUSTMENTS ARE DONE, PLEASE CHECK THE FOLLOWING:**


- A. Confirm that the launching arm is **STRAIGHT**, remove the arm and visually inspect the same (after some time of use, a slight "banana shape" in the working direction is normal and acceptable). However, if the arm is bent either up or down, it will severely effect the target flight, or cause target breakage. In such a case, replace the arm before checking further. If you think the arm needs adjustment please see next page.
- B. Verify that the elevator is adjusted correctly, i.e. a clearance between the highest point of the elevator and the bottom rim of the target - (in its ready to fire position), of at least 1/4" or more.
- C. Confirm that the target retainer brush is "holding" the target close to the launching arm (a distance between the target and the launching arm of about a 1/4" is acceptable).

**THE FOLLOWING PICTURES AND INSTRUCTIONS WILL HELP YOU MAINTAIN YOUR BEOMAT LAUNCHER. PLEASE CHECK YOUR LAUNCHER PERIODICALLY. PLEASE KEEP THE LAUNCHER CLEAN, AND DO NOT LOAD BROKEN TARGETS.**

## **THE TARGET NEST**


The birds view of the target nest shows you all the details for an excellent target performance. The launching arm (# 1), should be roughly parallel with the left side of the chassis, or as shown in this drawing. The target guide rail is an important part of the target performance. This guide rail (# 2) has had various lengths through the years, and is now at the exact length of six inches. Please note the exact position of the guide rail. (Should you have machines of an earlier model, it will be a great advantage to arrange the target nest to these exact specifications together with a new brush. If the guide rail is longer than 6 inches, it is important that it be shortened to that length before adjusting it to the position shown here).

We have recently improved the nest brush itself (# 3) in order to have the optimum performance, and the brush is now mounted directly onto the magazine table. (The brush in this picture is equipped with a bracket (# 4), and as such applies to earlier style machines). The brush position is essentially the same regardless of mounting, should the brush require replacement, detailed instructions are furnished with the brush.



# CORRECT LAUNCHING ARM ADJUSTMENT PROCEDURE.

## VISUAL CHECK ILLUSTRATION




Check the launching arm adjustment with the launcher in the cocked position, viewing the arm and the target from the rear of the machine (refer to illustration at left).

Then shut off power and release the launcher by its toggle switch at the square receptacle box on the cord. (Or, if not existing, it is perfectly safe to release the arm using your index finger behind the tip of the arm, pushing it to start after the power has been shut off)


## ADJUSTMENT ILLUSTRATION

Procedures, (this view from the launchers own left side). Please note the position of the launching arm carrier. Refer to illustration above, before any adjustments are made. Proceed with the adjustment, use a 6 mm Allen tool to loosen bolt (indicated by arrow in illustration at right), about 1/2 to 1 turn, while supporting the launching arm with your left hand. Then lightly pry the launching arm carrier up or down on the main shaft with a medium size screwdriver, "walking" it to the desired position on the shaft. Repeat the above steps until the correct adjustment is obtained. Tighten the retainer bolt to **17-20 Lb. Ft.** (or 25-30 NM or 2.2-2.6 Kpm).



## MICRO SWITCH ADJUSTMENT

MAY BE ONE OF THE MOST COMMON CORRECTIONS ON THE MACHINE. FOR INSTANCE, IF THE MACHINE SHOULD START RELEASING TARGETS ON ITS OWN, AN ADJUSTMENT OF THE SWITCH TO THE LEFT, OR DOWNWARDS MAY BE A CORRECT SOLUTION.




The micro switch is controlling the re-cocking function of the launcher, and is activated by the launching arm. To adjust the height of the switch, simply loosen the two slot mounted screws (shown) and slide the entire switch body up or down. Another adjustment, (not visible in this picture) is that the entire bracket may be moved in the slotted mounting holes at top of bracket, allowing the switch assembly to be moved left or right. NOTE, the ideal position as shown, with the launching arm parallel with the left side of the chassis and the leading edge of the arm flush with the tip of the switch lever.



## Adjustment of the back lash brake.

In order to eliminate vibrations, a brake band with a one-way clutch is installed on the launching arm shaft. Tightening of the adjusting bolt, turning clockwise, will increase the brake efficiency. Please adjust so that the launching arm stops without vibrations "on the corner of the chassis." If a moderate tightening of this bolt does not have the desired effect, the sprague within the band may be faulty or worn.




## Elevator clearance.


The only reason for the elevator to require an adjustment would be if there is a lot of broken targets loaded in the machine. The result is that the elevator must cut through the target pieces, which in turn may cause a slight bend in the parallel arm assembly, thus, necessitating adjustment. The machine itself will not break any targets unless it is severely out of adjustment. (under severe conditions it may be necessary to either straighten or replace the parallel arm assembly).

The elevator should be checked with the power shut off and the machine released manually, i.e. not by the electrical switch, since the elevator will be moving upwards immediately when released by the electrical switch.

The distance from the highest point of the elevator to the bottom rim of the target should be a minimum of a  $\frac{1}{4}$  inch, as per illustration on the right.



## Elevator height adjustment.




Adjustment of the elevator, is done by loosening the small bolt, as shown, at the bearing riser on the parallel arm assembly. Then by sliding the bearing riser for or aft you will be changing the height of the elevator. (Again, the machine must be released manually in order to have the elevator position correct).


And of course, as always, --- the power must be shut off and the launcher released before any adjustments are made.

## Target separating knife

A target separating knife is installed on your Beomat machine. The knife is installed in a reversed position for the reason that it must be adjusted individually for every manufacture of targets. When activated, loosen the nut at the top, reverse the knife and use the installed washers to adjust the height. It may be necessary to bend the knife slightly up or down in order to very precisely adjust the knife. The knife will perform excellently with wet targets, but bear in mind, if not adjusted properly it will cause more harm than good.



## Drive belt adjustment




A pair of regular V-belts, are utilized between the reduction gear and the launcher main shaft. After some time, a year or two, it may be necessary to tighten the belts slightly. This is done by loosening the two fasteners as shown, about one turn or at the most a turn and a half, then by tightening the belt tension bolt, shown, about one full turn. (It should be understood that too great a belt tension will put unnecessary pressure on the drive mechanism). Then re-tighten the two fasteners at the gear bracket.

## Leaf spring

A leaf spring is installed to provide an "ease down" of the target stack. Adjustment is normally not required, however, if the spring should need replacement, or come out of position, it should be adjusted so; that when the magazine is filled with targets and after delivering one target to the elevator, the full stack of targets will ease down as the magazine starts indexing again.



## Launching table fasteners



Never adjust the launching table fasteners. They have been adjusted once and for all. **ANY TAMPERING WITH, OR ADJUSTMENT OF THE SAME, WILL INVALIDATE YOUR WARRANTY.**

### INDEX

ADJUSTMENT GUIDE.....	4.
BACK LASH BRAKE ADJUST.....	6.
DRIVE BELT ADJUST.....	7.
ELECTRICAL CONNECTIONS.....	3.
ELEVATOR CLEARANCE / ADJUST.....	6.
LAUNCHING ARM ADJUST.....	5.
LEAF SPRING .....	7.
MICRO SWITCH ADJUST.....	5.
TRAP INSTALLATION.....	2.
SPRING TENSION, LENGTH OF THROW.....	3.
TARGET NEST.....	4.
TARGET SEPARATING KNIFE.....	6.
TARGET TRAJECTORY SETUP.....	2-3.
WARNING PAGE.....	1.

**INSTALLATION AND OPERATING  
GUIDE  
FOR BEOMAT MS 400, MS 700, MS 900.**

# **WARNING**

ANY CLAY TARGET LAUNCHER REGARDLESS OF MANUFACTURE, BY THE NATURE OF ITS PURPOSE, CREATES A CERTAIN HAZARD WHERE THE OWNER/USER MUST PROVIDE FOR THE SAFE OPERATION OF SUCH UNIT AT HIS/HER/THEIR OWN EXPENSE AND RESPONSIBILITY.

DO NOT INSTALL THE LAUNCHER SO; THAT THE LAUNCHING ARM AREA IN THE FRONT, OR THE TARGET EXIT AREA AT THE RIGHT FRONT CORNER OF THE MACHINE IS UNPROTECTED. FURTHER, DO NOT ALLOW ENTRANCE TO THE HOUSE ON THE LEFT SIDE OF THE MACHINE, (THE MACHINE'S OWN LEFT SIDE).


IT IS REQUIRED THAT THE ELECTRICAL HANDY BOX IS MOUNTED IN SUCH A LOCATION THAT THE LAUNCHER MAY BE RELEASED BY IT'S WIRE REMOTE SWITCH BEFORE ANYONE ENTERS THE HOUSE.

KEEP THE MACHINE AREA CLEAN AT ALL TIMES, REMOVE ALL EMPTY TARGET BOXES - IT GREATLY REDUCES SAFETY HAZARDS.

SHUT OFF POWER AND RELEASE THE LAUNCHER BEFORE PERFORMING ANY WORK WHATSOEVER IN THE HOUSE - WHEN LOADING TARGETS, OR MAKING ANY CHANGES ON THE LAUNCHER ITSELF.

WARNING PAGE



# Installation of your Beomat Skeet machines.



**High house;** determine the exact position of the targets emerging point in relation to shooting station # 1. The base chord of the field should correspond with the centerline of shooting station 1. The target should be emerging on the centerline of station 1.

**Low house:** Again, determine the exact position of the target at its emerging point in relation to shooting station # 7. The base chord of the field should correspond with the centerline of station 7. Set reference marks for the targets emerging point at the bottom and on one side of each "window", or use electrical/masking tape to set a "cross hair" across the window, this gives a very exact point to measure from. Measurements are the same for American as well as International skeet.

Before attempting to install the machines into respective house, the magazines must be removed by removing the 4 bolts in the center of the magazine, then lift the magazine straight off the launcher. (Do not remove the lock ring at the shaft), assemble in reverse order.



**High House.** By using the now established target emerging point, and the center hole (pivot hole) in the base plate of the machine, the following measurements will apply. The center hole (pivot) in the base plate of the machine is to be located 16" (41 cm) below the targets emerging point. The distance from the front wall to the pivot point in the base should be about 24" (61 cm). And, 5" (13 cm) offset to the (outside of the field), or left of the imaginary target trajectory line as seen from behind the machine. If the old Winchester pier is used, it will be necessary to increase the height of this pier about 4". This may be done, by using 2 pieces of 4" x 14" x 30" planks positioned across the old pier. It is important that the base plates are in level. Base plate dimension is 19" x 19" for both machines.

**Low House.** The base plate pivot hole must be located 21" (53 cm) below the targets emerging point. The pivot hole 24" (61 cm) setback from the front wall, and 5" (13 cm) offset to the (inside of the field), or left of the imaginary trajectory line as seen from behind the machine.

**High house & Low house.** Before bolting the machine to the pier, install the launching arm guard, the magazine and the launching arm. Connect the wiring as per wiring instructions on the next page. Load a small amount of targets and test fire the machine to determine that the emerging point is correct, make minor adjustments by moving the machine side to side, forward or aft, until a satisfactory result has been achieved. The turnbuckle at the base is to change the elevation of the target. Make sure that these procedures are conducted safely, with the launcher released when adjustments are made.




## **Electrical compatibility/connections.**

Standard, non-oscillating single target launchers, MS400, 700, 900, are equipped with a 120 volt AC release system for compatibility with your existing Winchester/Ohlin installation. The electrical connections are identical to your Winchester/Ohlin machines/field wiring. The machines are equipped with a switch box, with an ON-OFF-Momentary function. The momentary function provides a safe release for the machines. The electrical connections in your skeet house should be color for color; black = HOT (or face), white = NEUTRAL (or 0), green = GROUND (or earth), red = RELEASE. (Please note, the wiring is European color, but with colored sleeves corresponding to US standard).


NO PICTURE AVAILABLE

## **Installation setup / target trajectory adjustments.**

There are three adjustments for the target trajectory. One, for the leveling of the target; the right side support leg is adjustable, please note the two lock bolts and a height adjustment bolt which may be adjusted to accommodate any specific target for a perfectly flat trajectory. The vertical adjustment (setting the target height), is simply done by the turnbuckle. The next adjustment is providing a horizontal movement. Once the target path has been established, a minor side to side adjustment may be done by loosening the bolt at the base plate slot, then turning the machine to either side for wind adjustment.



## **Installation setup / spring tension adjustment.**



A spacer system is utilized for the changing of spring tension, (changing of target throwing distance). The spring is installed without pre-load, and two different systems for setting the target flight distance may be used. ONE, that the spacers may be used to obtain the distance desired with the spring as is. TWO, that the lock nut at the end of the spring be loosened and by turning the eyelet on the outside clockwise thus increasing the spring tension. When the desired distance is obtained, tighten the lock nut, and use the spacer system for quick changes of more demanding games. The thick spacer will increase the target flight distance by about 10 yards and the other spacers in descending order down to 1 yard.



# ADJUSTMENT GUIDE

YOUR BEOMAT LAUNCHER HAS UNDERGONE COMPLETE PRE-DELIVERY SERVICE AND SHOULD NOT REQUIRE ANY ADJUSTMENTS WHATSOEVER AT THE TIME OF INSTALLATION. IF THE LAUNCHER IS NOT PERFORMING PROPERLY AFTER INSTALLATION, (THE MACHINE MAY HAVE BEEN EXPOSED TO FREIGHT DAMAGE). IF SO, PLEASE CALL BEOMAT OF AMERICA IMMEDIATELY, AND AT ANY TIME, (408) 379-4829. IF AFTER BUSINESS HOURS PLEASE REMAIN ON THE LINE, THE CALL WILL TRANSFER TO A SELECTED TECHNICAL SUPPORT PHONE AFTER SEVEN RING SIGNALS.

## IF YOUR LAUNCHER IS NOT PERFORMING CORRECTLY, BEFORE ANY ADJUSTMENTS ARE DONE, PLEASE CHECK THE FOLLOWING:


- A. Confirm that the launching arm is **STRAIGHT**, remove the arm and visually inspect the same (after some time of use, a slight "banana shape" in the working direction is normal and acceptable). However, if the arm is bent either up or down, it will severely effect the target flight, or cause target breakage. In such a case, replace the arm before checking further. If you think the arm needs adjustment please see next page.
- B. Verify that the elevator is adjusted correctly, i.e. a clearance between the highest point of the elevator and the bottom rim of the target - (in its ready to fire position), of at least 1/4" or more.
- C. Confirm that the target retainer brush is "holding" the target close to the launching arm (a distance between the target and the launching arm of about a 1/4" is acceptable).

THE FOLLOWING PICTURES AND INSTRUCTIONS WILL HELP YOU MAINTAIN YOUR BEOMAT LAUNCHER. PLEASE CHECK YOUR LAUNCHER PERIODICALLY. PLEASE KEEP THE LAUNCHER CLEAN, AND DO NOT LOAD BROKEN TARGETS.

## THE TARGET NEST


The birds eye view of the target nest shows you all the details for an excellent target performance. The launching arm (# 1), should be roughly parallel with the left side of the chassis, or as shown in this drawing. The target guide rail is an important part of the target performance. This guide rail (# 2) has had various lengths through the years, and is now at the exact length of six inches. Please note the exact position of the guide rail. (Should you have machines of an earlier model, it will be a great advantage to arrange the target nest to these exact specifications together with a new brush. If the guide rail is longer than 6 inches, it is important that it be shortened to that length before adjusting it to the position shown here).

We have recently improved the nest brush itself (# 3) in order to have the optimum performance, and the brush is mounted directly onto the magazine table. (The brush in this picture is equipped with a bracket (# 4), and as such applies to earlier style machines). The brush position is essentially the same regardless of mounting, should the brush require replacement, detailed instructions are furnished with the brush.



# CORRECT LAUNCHING ARM ADJUSTMENT PROCEDURE.

## VISUAL CHECK ILLUSTRATION




Check the launching arm adjustment with the launcher in the cocked position, viewing the arm and the target from the rear of the machine (refer to illustration at left).

Then shut off power and release the launcher by its toggle switch at the square receptacle box on the cord. (Or, if not existing, it is perfectly safe to release the arm using your index finger behind the tip of the arm, pushing it to start after the power has been shut off)


## ADJUSTMENT ILLUSTRATION

Procedures, (this view from the launchers own left side). Please note the position of the launching arm carrier. Refer to illustration above, before any adjustments are made. Proceed with the adjustment, use a 6 mm Allen tool to loosen bolt (indicated by arrow in illustration at right), about 1/2 to 1 turn, while supporting the launching arm with your left hand. Then lightly pry the launching arm carrier up or down on the main shaft with a medium size screwdriver, "walking" it to the desired position on the shaft. Repeat the above steps until the correct adjustment is obtained. Tighten the retainer bolt to **17-20 Lb. Ft.** (or 25-30 NM or 2.2-2.6 Kpm).



## MICRO SWITCH ADJUSTMENT


MAY BE ONE OF THE MOST COMMON CORRECTIONS ON THE MACHINE. FOR INSTANCE, IF THE MACHINE SHOULD START RELEASING TARGETS ON ITS OWN, AN ADJUSTMENT OF THE SWITCH TO THE LEFT, OR DOWNWARDS MAY BE A CORRECT SOLUTION.



The micro switch is controlling the re-cocking function of the launcher, and is activated by the launching arm. To adjust the height of the switch, simply loosen the two slot mounted screws (shown) and slide the entire switch body up or down. Another adjustment, (not visible in this picture) is that the entire bracket may be moved in the slotted mounting holes at top of bracket, allowing the switch assembly to be moved left or right. NOTE, the ideal position as shown, with the launching arm parallel with the left side of the chassis and the leading edge of the arm flush with the tip of the switch lever.

## Adjustment of the back lash brake.

In order to eliminate vibrations, a brake band with a one-way clutch is installed on the launching arm shaft. Tightening of the adjusting bolt, turning clockwise, will increase the brake efficiency. Please adjust so that the launching arm stops without vibrations "on the corner of the chassis." If a moderate tightening of this bolt does not have the desired effect, the sprague within the band may be faulty or worn.




## Elevator clearance.


The only reason for the elevator to require an adjustment would be if there is a lot of broken targets loaded in the machine. The result is that the elevator must cut through the target pieces, which in turn may cause a slight bend in the parallel arm assembly, thus, necessitating adjustment. The machine itself will not break any targets unless it is severely out of adjustment. (under severe conditions it may be necessary to either straighten or replace the parallel arm assembly).

The elevator should be checked with the power shut off and the machine released manually, i.e. not by the electrical switch, since the elevator will be moving upwards immediately when released by the electrical switch.

The distance from the highest point of the elevator to the bottom rim of the target should be a minimum of a  $\frac{1}{4}$  inch, maximum about a  $\frac{1}{2}$  inch, as per illustration on the right.



## Elevator height adjustment.




Adjustment of the elevator, is done by loosening the small bolt, as shown, at the bearing riser on the parallel arm assembly. Then by sliding the bearing riser for or aft you will be changing the height of the elevator. (Again, the machine must be released manually in order to have the elevator position correct).


And of course, as always, --- the power must be shut off and the launcher released before any adjustments are made.

## Target separating knife

A target separating knife is installed on your Beomat machine. The knife is installed in a reversed position for the reason that it must be adjusted individually for every manufacture of targets. When activated, loosen the nut at the top, reverse the knife and use the installed washers to adjust the height. It may be necessary to bend the knife slightly up or down in order to very precisely adjust the knife. The knife will perform excellently with wet targets, but bear in mind, if not adjusted properly it will cause more harm than good.



## Drive belt adjustment




A pair of regular V-belts, are utilized between the reduction gear and the launcher main shaft. After some time, a year or two, it may be necessary to tighten the belts slightly. This is done by loosening the two fasteners as shown about one turn or at the most a turn and a half, then by tightening the belt tension bolt, shown, about one full turn. (It should be understood that too great a belt tension will put unnecessary pressure on the drive mechanism). Then re-tighten the two fasteners at the gear bracket.

## Leaf spring

A leaf spring is installed to provide an "ease down" of the target stack. Adjustment is normally not required, however, if the spring should need replacement, or come out of position, it should be adjusted so; that when the magazine is filled with targets and after delivering one target to the elevator, the full stack of targets will ease down as the magazine starts indexing again.



## Launching table fasteners



Never adjust the launching table fasteners. They have been adjusted once and for all. **ANY TAMPERING WITH, OR ADJUSTMENT OF THE SAME, WILL INVALIDATE YOUR WARRANTY.**

### INDEX

ADJUSTMENT GUIDE.....	4.
BACK LASH BRAKE ADJUST.....	6.
DRIVE BELT ADJUST.....	THIS PAGE.
ELECTRICAL CONNECTIONS.....	3.
ELEVATOR CLEARANCE / ADJUST.....	6.
LAUNCHING ARM ADJUST.....	5.
LEAF SPRING .....	THIS PAGE.
MICRO SWITCH ADJUST.....	5.
SKEET INSTALLATION.....	2.
SPRING TENSION, LENGTH OF THROW.....	3.
TARGET NEST.....	4.
TARGET SEPARATING KNIFE.....	6.
TARGET TRAJECTORY SETUP.....	3.
WARNING PAGE.....	1.